

# Nursing Professional Development

# Intravenous Guidelines for the Adult Patient

Resource Manual

Quality, Patient Safety & Interprofessional Practice February 2020





#### **Table of Contents**

Certification Criteria.	
Introduction	3
Anatomy of Upper Extremity Veins	5
Comparison of Veins and Arteries	6
PVAD Initiation Guidelines	7
Site Selection and Vein Criteria	
Initiation Procedure	
PVAD Dressing.	
Saline Lock Maintenance.	11
Intravenous Monitoring	12
IV Medication Therapy	15
Intermittent Infusions: IV Pump and Syringe Pump	19
Intravenous Bolus Medications	21
Complications of IV Therapy	
Troubleshooting	
References	25
Appendix A – Intravenous Certification Skills Checklist	26
Appendix B – Certification Test for Initiation of PVAD and Infusion Therapy	28

#### **Certification Criteria**

Regulated Healthcare Professionals (RHPs) at Quinte Healthcare Corporation (QHC) who are expected to initiate and maintain intravenous therapy within their scope of practice must be certified to initiate peripheral venous access devices (PVADs) and to initiate and maintain infusion therapy. The steps required for certification are as follows:

- 1. Attendance at a theory session focused on peripheral venous access device (PVAD) access, initiation and maintenance. IV pump training will be delivered in this session including safe operation of the Plum pump used throughout QHC as well as the Excelsior syringe pump.
- 2. Review the resource manual entitled Intravenous Guidelines for the Adult Patient. Achieve a minimum of 80% on the certification test (Appendix B).
- 3. A minimum of two successful/competent PVAD initiations observed by a clinical certified and competent in IV initiation.
- 4. Completion of the skills checklist for each supervised attempt. (Appendix A).

### **Continuing Competence**

Regulated Health Professionals (RHPs) at QHC are expected to review all skills related to the insertion and maintenance of PVADs on an ongoing basis to ensure continued competence. If at any time the RHP feels additional review/retraining is required, it is the responsibility of the RHP to seek additional education/resources from the manager, or clinical educator/delegate to ensure continued competence related to these skills. Nurses are professionally responsible for ensuring that they have the requisite knowledge, skill and judgment necessary to provide safe and effective infusion therapy (CNO, 2002).


#### Introduction

#### Peripheral Venous Access Device

- 1. A PVAD is a peripheral vascular access device, more commonly referred to as an IV.
- 2. At QHC, RNs, RPNs and MRTs can initiate a PVAD, maintain an IV infusion, and administer medications via the intravenous route, within their individual scope of practice and according to hospital policy.
- 3. Maintaining intravenous infusion therapy is a routine daily nursing practice at QHC, however it is not without significant risks that the nurse/healthcare provider must be aware of and responsive to. These risks can include nerve or vessel damage during initiation of the PVAD, extravasation of fluids or medications during infusion, phlebitis of the vein and systemic effects of intravenous therapy including fluid overload.
- 4. Vein selection is important. Select the smallest PVAD which will allow for the therapy being delivered. For example, a large bore, short IV catheter inserted into the antecubital vein may be used for the trauma or cardiac arrest patient, however it is not ideal to use the antecubital vein for most routine infusions. The most common IV catheter utilized at QHC is the 20 gauge 1 ½" and will suffice for most therapies. However, for an elderly patient who has frail veins, a 22 gauge IV catheter can be used as it is sufficient diameter to allow for infusions and blood transfusions as needed.
- 5. It is policy at QHC that vein selection occurs from distal to proximal in the upper extremities only. This means begin looking for an IV site on the patient's hand, move up the forearm, then to the antecubital vein only as a last resort.
- 6. The risk of nerve damage from insertion of a PVAD is increased if proper vein selection criteria is not followed. This can cause temporary to long-standing peripheral neurovascular complications for patients. It is important to avoid the inner aspect of the wrist in order to decrease the risk of damage to the radial, ulnar, and/or median nerves which are located within a five centimetre (cm) radius of the inner aspect of the wrist (Masoorli, 1998; Thrush, 1995). (RNAO, 2008).
- 7. There are many considerations when selecting a site for PVAD insertion which must be considered. Assess the patient's condition, age, diagnosis, comorbidities, condition of the vasculature at the insertion site and proximal to the intended insertion site, condition of skin at intended insertion site, history of previous venipunctures and access devices, type and duration of infusion therapy, and patient preference for VAD site selection. (INS, 2016). Use the venous site most likely to last the full length of the prescribed therapy, using the forearm to increase dwell time, decrease pain during dwell time, promote self-care, and prevent accidental removal and occlusions. Consider veins found on the dorsal and ventral surfaces of the upper extremities, including the metacarpal, cephalic, basilic, and median veins.

- 8. Avoid the following areas:
  - the ventral surface of the wrist due to pain on insertion and possible nerve damage
  - areas of flexion
  - areas of pain on palpation
  - compromised areas and sites distal to these compromised areas, such as areas with open wounds; areas on an extremity with an infection; veins that are compromised (eg, bruised, infiltrated, phlebitic, sclerosed, corded, or engorged)
  - areas with valves
  - areas of previous infiltration or extravasation
  - the extremity on the side of a planned procedure
  - veins in an upper extremity on the side of breast surgery with axillary node dissection, and/or lymphedema
  - after radiation therapy to that side of the body
  - with an arteriovenous fistula/ graft
  - the affected extremity from a cerebrovascular accident
- 9. Do **not** use veins of the lower extremities unless necessary due to risk of tissue damage, thrombophlebitis, and ulceration. (RNAO, 2008). At QHC we do **not** use the lower extremity veins for PVAD insertion in the adult population. Sometimes the lower limbs are utilized for venipuncture in infants/small children.
- 10. Do **not** attempt PVAD more than 2 times. If unsuccessful, contact another member of the healthcare team to assist, who has demonstrated competence in PVAD insertion. Document all attempts, both unsuccessful and successful and be sure to monitor any areas which have been attempted, for swelling, bruising or ongoing complaints of discomfort from the patient, which may indicate complications of PVAD insertion. Report any untoward findings to the MRP.

#### ANATOMY OF UPPER EXTREMITY VEINS



#### **COMPARISON OF VEINS AND ARTERIES**




Image retrieved from: Urden, S. (2009) Critical Care Nursing: Diagnosis and management (6<sup>th</sup> ed.) http://www.nursingconsult.com

#### **ARTERIES VEINS** No pulsation Pulsates Blood is under pressure and flows rapidly Sluggish flow Bright pink - red colour Dark red in colour Prolonged direct pressure needed to stop Shorter duration of pressure needed to blood flow from a venipuncture site stop blood flow from the venipuncture site Valves prevent backflow No valves, blood moves under pressure of the heart beat Thin muscular wall Thick muscular wall Veins are unlikely to spasm and are more If fluid is infused into a superficial artery, the likely to collapse; may spasm with arterial spasm results in blanching and irritating solutions or trauma ischemic injury

# **Peripheral Vascular Access Device Initiation Guidelines**

Steps	Rationale
Verify the order for IV therapy. Note the solution, rate and duration of	Risk management.
therapy.	
Gather equipment:	Be prepared.
Alcohol wipes	
Tourniquet	
Peripheral Vascular Access Device (PVAD)	
<ul> <li>Dressing –transparent semi permeable membrane "opsite"</li> </ul>	
Gauze and tape	
• Gloves	
<ul> <li>Primed positive pressure displacement device "saline lock" or</li> </ul>	
macro bore extension set	
IV solution and primed tubing if needed	
Syringe with 5 mL of normal saline for flush.	
Confirm proper identification of patient using two unique identifiers.	Risk management.
Explain procedure to the patient and obtain consent.	Reduces anxiety
	Risk management.

### Site Selection and Vein Criteria

Steps	Rationale
Selecting a vein: Veins of the hand and forearm	The site of choice, moving from distal to proximal. Consider the purpose of therapy and the size of the PVAD required when selecting the vein. Avoid a 5cm radius at the wrist to prevent nerve damage.
Antecubital fossa	Only use in an emergency situation or if the antecubital fossa is the only accessible site. (only as last resort or when high volume fluid resuscitation is required, ie. trauma, hemorrhage, septic shock, cardiac arrest.
Lower limbs – are <b>not</b> used at QHC in adults	Requires careful consideration of the contraindications, used only with a physician's order in extenuating circumstances.
Avoid areas painful to palpation and bony prominences	Pain may indicate a nodule or inflammation in the vein. The skin over bony areas is very thin- painful for PVAD insertion.
Avoid areas of flexion	Difficult to maintain IV infusion and increased risk for phlebitis, infiltration and excessive vessel damage.
Do not use limb on same side of mastectomy, dialysis shunt or paralysis.	Increases risk for complications such as infection, lymphedema or vessel damage.

# **Vein Distention**

Steps	Rationale
Place limb in dependent position.	Improves venous dilation and visibility.
Distend vein: Apply flat tourniquet 8 to 15 cm above the intended site <b>OR</b> apply BP cuff to the upper arm to assess limb for venous distention.	Primary vein filling. BP cuff reduces the risk of skin tears in fragile skin.
<ul> <li>If venous distention is not obtained:</li> <li>Gently tap vein</li> <li>Release tourniquet, gently rub the arm from wrist to elbow</li> <li>Place a warm cloth in patients' hand or wrap the arm with a warm towel</li> <li>Ask patient to make a fist and hold Remove tourniquet if more than 2 minutes.</li> </ul>	Relieve vasoconstriction. A warm environment promotes venous distention. Increases venous filling above the hand. **Vigorous friction and multiple tapping of the veins especially in older adults causes hematoma and/or venous constriction** Tourniquet should be removed after 2 minutes maximum to allow blood flow to return to the distal portions of the limb.

### **Initiation Procedure**

### **PVAD** initiation video link:

http://www.bd.com/infusion/products/ivcatheters/resources/

Steps	Rationale
Perform hand hygiene and apply gloves.	Prevent the transmission of microorganisms.
Distend the vein. Palpate the vein in the direction of blood flow. Vein should be soft and bouncy, elastic to the touch – pulseless. Select a vein large enough to accommodate intended therapy.	See vein distention techniques.
Cleanse site with 60 second alcohol friction rub,	Allows for antimicrobial effect.
starting at the centre and working outward. Allow to air dry completely.	Wet alcohol will cause pain.
Remove the PVAD from the protective sheath and examine the tip. Rotate the hub of the catheter 360 degrees and ensure catheter is seated back in the notch.	To detect any defects. Ensures the tip seal is broken to facilitate stylet retraction.
Immobilize the vein. Anchor the vein below the site by placing the thumb over the vein 4 to 5 cm below the insertion site and a finger above the insertion site gently stretching the skin in the direction of insertion. This can also be done by applying gentle contra-lateral stretching of the skin.	To prevent rolling and minimize trauma during catheter advancement.

### Intravenous Guidelines for the Adult Patient

Steps	Rationale
If re-palpation is necessary, re-cleanse site with	To maintain asepsis.
alcohol wipe and let dry.	10 mamam asepsis.
alcohol wipe and let dry.	
Using the <b>smallest</b> PVAD capable of providing the	Reduces trauma to vein.
prescribed therapy, puncture skin by inserting the	Reduces trauma to vem.
needle bevel up at 10 to 30-degree angle slightly	
distal to actual site of venipuncture using either	
direct or indirect insertion technique.	
direct of mancet insertion technique.	
Observe for blood return confirming entry of the	Prevents hematoma.
vessel. Once in the vessel lower the angle almost	Ensures complete entry of the catheter into
flush with the skin and advance the entire PVAD	the vein.
unit approximately ¼ inches. 20 gauge and smaller	
you will immediately see blood along the catheter	
shaft confirming entry of the vessel, 18 gauge and	
larger blood will not be seen until it enters the	
flashback chamber.	
Advance the PVAD off the stylet into the vein until	To prevent movement of the needle in the
the hub rests at the insertion site. Stabilize the	PVAD.
catheter with one hand and release the tourniquet	
with the other. Place a finger on the hub of the	
PVAD to stabilize and retract the stylet by pressing	
the white button.	
Press the tip of the primed macro bore extension	Luer locked connection avoids accidental
tubing or clave connector into the port and twist 1/4	disconnects.
turn. Luer the slip connector.	
Electronida a constituit and if acing a constant	Duran de alad Camardia y ad DVA Dain
Flush with normal saline and if using an extension	Prevents clot formation at PVAD tip.
set, clamp the extension tubing prior to removing the syringe.	
Tape and secure with appropriate dressing.	Prevents movement of PVAD within the vein
Tupe and secure with appropriate dressing.	decreasing the risk of complications.
	Prevents accidental dislodging of PVAD.
	Ensures PVAD can be visualized and
	assessed hourly.
Apply tab with date of insertion and gauge of	
PVAD and initials.	
Initiate infusion /saline lock as per doctor's order.	IV tubing change performed q96 hours
Note correct solution and rate. Date IV tubing.	
Discard sharps in the designated sharps container	Routine practices.
and perform hand hygiene	
Document the intervention in the patient's health	Record all unsuccessful and successful
record.	attempts, site selected, size of catheter used,
	any untoward complications, patient
	tolerance of procedure

**PVAD Dressing** 

Steps	Rationale
Equipment  •alcohol wipes  •transparent semi permeable membrane (TSM)  "opsite" or tegaderm  •sterile gauze and tape	Be prepared.
Perform hand hygiene and apply clean gloves.	Prevent the transmission of microorganisms.
Do not put tape on the TSM dressing or under the dressing.	Puts PVAD at risk during dressing removal and breaks aseptic technique.
Remove the dressing if soiled or no longer occlusive. Remove old dressing from outer edges in while securing the PVAD by holding the hub in place with one finger.	May be changed PRN. Prevent accidental removal.
Cleanse site of blood and debris with alcohol wipe.	Reduce the risk of site infection.
Apply transparent semi permeable membrane "opsite" or tegaderm using sterile technique to cover the site and hub but not the connector. Use sterile gauze and tape if patient has sensitivity to TSM.	Reduce the risk of site infection.  Gauze dressings even when dry and intact must be changed daily.
Further stabilize with tape across the connector and tubing.	To stabilize the connection and prevent drag on the PVAD.
Perform hand hygiene.	Prevent the transmission of microorganisms.

# **Saline Lock Maintenance**

Steps	Rationale
Gather equipment	Be prepared.
• 5 or 10 mL syringe or larger and sterile	Note: There is less pressure with larger
normal saline or pre-filled syringe of saline for	syringes when infusing, more pressure when
injection if available	withdrawing.
Alcohol wipes	
Perform hand hygiene and apply clean gloves.	Prevent the transmission of microorganisms.
Total name my group and apply crown groves.	110 ( one the transmission of mitted or gamesing)
Draw up 5 mL of sterile saline in a 5 or 10 mL luer	Use the bag spike where available.
lock syringe maintaining tip sterility.	os in the same of
The system of th	
Cleanse clave connector with alcohol wipe using	To maintain sterile fluid path.
30-second friction rub and allow to dry.	
Luer syringe onto the clave connector of the	Needle free system – all connections are
extension tube.	luered.
Unclamp the extension tube.	Opens fluid path.
Aspirate for blood return.	Assesses for patency.
In the presence of blood return, flush gently with	If no blood return, absence of resistance and
saline, monitoring for infiltration and tenderness. In	infiltration will ensure patency.
the absence of blood return, gently flush – if	
resistance is met do not continue.	
	D : 4 1 64
Do not empty the syringe completely.	Pressing the plunger to the bottom of the
	syringe creates a slight rebound action
	drawing blood back into the PVAD.
Clamp the extension tubing before removing the	Provides positive pressure lock.
syringe (if using extension set).	
Remove the syringe.	
Perform hand hygiene.	Prevent the transmission of microorganisms.
Document the intervention in the patient's health	Clear communication.
record and on the CMAR.	
	1

**Intravenous Monitoring** 

THE TAVELOUS IVE	
<u>Steps</u>	Rationale
Note the date of initiation of site and tubing.	PVAD should not be left in place greater than 96 hours. Closed system tubing is changed Q96H or when the PVAD is resited. Administration set changes should coincide with peripheral IV site rotation. Some medications/solutions require more frequent tubing changes.
Ensure the PVAD is secured in place so that it	Movement of the PVAD increases the
cannot be advanced or pulled out.	risk for infection and phlebitis.
Assess the site Q1h for:	Drainage under the dressing may indicate
Clean and dry at the insertion site and	infiltration, phlebitis or infection.
visible through the semi-permeable	Redness at, or around the insertion site
membrane	and along vein indicates inflammation,
<ul> <li>Inflammation or infiltration</li> </ul>	induration and swelling with skin
<ul> <li>Tenderness</li> </ul>	temperature cooler than surrounding skin
Discolouration	may indicate infiltration.
	Increased temp may indicate phlebitis.
Note sluggish flow of IV fluid or frequent distal	This could be evidence of an interstitial
line occlusion alarms.	IV and requires further assessment.
Note the solution being infused and compare to	On each initial assessment the solution
doctor's order.	and rate should be verified with the order.
Monitor flow rate and site Q1h. Document rate and	Note gravity flow rate formula
solution changes at the time the intervention	Drops per minute = total mL ÷ total min
occurs. Clear the infusion pump and document the amount infused when the solution is changed	x the drop factor.
and/or at the end of each shift unless ordered more	(Weinstein, 2001, p. 199)
frequently. Pressure per Square Inch (PSI) should	
be documented once per shift. The maximum PSI setting for the adult patient is 6.	
Monitor fluid balance by completing accurate	Fluid balance is part of standard nursing
intake and output at a minimum of once per shift or	assessment of all patients. Chest
more often if required for IV rates greater than 30	assessment and monitoring for edema is
mL/hr. Daily weight should be completed as per physician order.	recommended for patients receiving continuous IV infusion greater than 30 mL/hr.
	Accurate intake includes the intravenous and all oral intake.
IV TKVO (To keen vein open) rate	TKVO rate is 30 mL/hr. unless ordered
IV TKVO (To keep vein open) rate.	otherwise by the physician.

### **Continuous Primary Infusion**

Continuous primary infusions consist of a solution prescribed at a specific rate and may or may not contain medication. Please refer to the section on IV medication administration for continuous infusions of medication.

The three categories of IV solutions are:

- Isotonic identical osmolality to body fluids and thus are used to replace extracellular volume
- Hypotonic osmolality less than that of body fluids thus are used to move fluid from the vascular space into the cells
- Hypertonic osmolality greater than that of body fluids thus are used to pull fluid into the vascular space from the cells

Isotonic Solutions	Hypotonic Solutions	Hypertonic
		Solutions
Dextrose 5% in water (D5W)	0.45% Sodium Chloride (half NS)	Dextrose 10% in
0.9% Sodium Chloride (NS)	0.33% Sodium Chloride (one-third NS)	water (D10W)
Lactated Ringers (LR)		Dextrose 50% in
(2/3 & 1/3)		water (D50W)
		3%-5% Sodium
		Chloride
		Dextrose 5% in NS
		Dextrose 5% in half
		NS
		Dextrose 5% in LR

### **Assessment of Infusion Therapy**

Assessment of intravenous therapy begins prior to initiation and throughout therapy. Assessment includes current hydration status, the goals of the therapy and the potential complications or risks associated with the therapy.

Factors to consider include:

- Age
- Weight
- Vital signs
- Lab values
- Skin turgor, oral mucous membranes, eyes, tongue
- Presence of edema
- Chest sounds per auscultation
- Disease process
- Surgical patient
- Fluid balance
- Mentation

It is important to know the rationale for the prescribed IV therapy and whether or not it continues to be an appropriate choice of therapy for each particular patient in order to prevent complications. Administer all IV fluids carefully. The nurse is responsible to carefully monitor intake and output and to document the fluid balance every shift and to report (if deficit or overload) to the physician.

Steps	Rationale
Perform hand hygiene and gather equipment.	Prevent the transmission of microorganisms.
Prime standard primary clave tubing fully with selected IV solution.	To ensure all air purged from tubing.
Cleanse saline lock port with alcohol wipe – 30 second friction rub. Assess for patency.	Aseptic technique.
Secure distal end of IV tubing into the cleansed port by pushing into port and twist ¼ turn. Tighten luer.	This is the initial securement.
Unclamp extension tubing.	Opens the fluid pathway.
Program the infusion pump noting the dose limit, which is the total amount of fluid in the bag at the time of initiation and the rate of infusion.	To prevent air in the distal line. To ensure that patient receives the IV fluids as per the physician's orders.
Note the fluid to be absorbed from the IV bag currently infusing.	Aids in calculating when you will need to prepare the next bag for infusion.
The infusion pump will alarm <i>dose end</i> to signal a new IV bag is needed. Select a bag of solution to match the physician's order. Remove the outer wrap. Check the expiry date on the bag.	Leakage of solution into the outer wrap may indicate the bag is punctured. Solution that is discoloured or cloudy should not be used. Return to SPD for quality assurance reporting. Check the IV solution for clarity. A small amount of moisture in the outer wrap is acceptable but a collection of fluid in the outer wrap may represent a damaged bag.
Stop the pump; remove IV bag port cover keeping the port sterile. Take down the empty IV bag; remove the tubing spike from the bag. Keeping the spike sterile thrust it into the port of the new IV bag.	
Follow the prompts on the pump for resetting the dose limit and restarting the pump.	At this time do not reset the amount infused.
When changing IV to IV lock, stop the pump, clamp tubing below the IV bag and clamp the extension set. Cleanse lower clave port with alcohol wipe x 30 seconds. Disconnect tubing from the clave extension set and luer tubing tip onto lower clave port.	To maintain positive pressure in the PVAD.  To maintain tubing for intermittent infusions if ordered.  Flush the lock with 5 mL of normal saline.
13. Perform hand hygiene.	Prevent the transmission of microorganisms.

### **IV Medication Therapy**

IV medications may be ordered when:

- a. A patient needs a rapid therapeutic effect
- b. The medications cannot be absorbed through the GI tract
- c. The patient can receive nothing by mouth and the drug would be irritating or painful if given intramuscularly or subcutaneously
- d. A controlled administration rate is required
- e. The medication is only available for IV administration

#### **Advantages and Disadvantages**

Advantages of IV medications therapy:

- > Provides immediate drug action by producing therapeutic blood levels rapidly
- Provides an alternate route if the oral route cannot be used
- > Eliminates absorption problems allowing for accurate titration and causing the patient less discomfort
- ➤ Allows drug delivery to be stopped immediately if an adverse reaction occurs
- Preferred route of medication administration in emergencies

Disadvantages of IV medications therapy:

- > Requires vascular access
- > Adverse reactions
- > Solution and drug incompatibilities resulting from binding of two drugs, physical alterations and chemical alterations

IV medications go directly into the patient's circulation, quickly achieving therapeutic blood levels, which is the reason why IV doses are often much smaller than oral doses. If an adverse reaction occurs, IV drug delivery can be stopped immediately. With other routes, absorption would continue until the drug was physically removed by vomiting, gastric lavage or dialysis.

### **Delivery Methods**

Intravenous infusion medications enter the venous system directly and therefore can cause rapid effects. Special attention is given to drug preparation and dose calculation. The nurse confirms safe medication administration by using critical inquiry and evidence informed practice and is aware of the desired action and potential side effects of each medication, as well as the desired outcome. The current **QHC IV Policy** and the **Ottawa Parenteral Drug Therapy Manual** should be consulted for all medication infusions regarding method of infusion (above or below the drip chamber), rate of infusion, proper dilution of medications and compatibility.

Utilizing the peripheral vascular access method, solutions will be administered through a vein in the arm or hand, or occasionally the foot (this site must be ordered by a physician at QHC). The peripheral vascular method is used for short term (less than 4 weeks) or intermittent therapy.

With the central vascular access therapy method, solutions are administered through a central vein, such as the right or left subclavian or the internal or external jugular. This method is used when the patient needs a large volume of fluid, or when the fluid is a hypertonic solution, a caustic drug, or a high energy parenteral nutrition solution. It may also be used in an emergency situation when a patient has inaccessible peripheral veins or needs long term therapy at home, or in hospital.

#### Intravenous Guidelines for the Adult Patient

Many parenteral medications are highly alkaline and irritating to muscle and subcutaneous tissue. Thus, the IV route is best to minimize patient discomfort. The nurse administers drugs intravenously by four methods:

#### 1. Continuous Infusion:

- Medication mixed within large volumes of IV fluids (admixture)
- Continuous infusions of IV medications should be run via the primary line (e.g. Pantoloc, Heparin, KCL)
- TPN is infused via a designated line or port. Please refer to TPN guidelines for more information.

#### 2. Intermittent Infusion:

- "Piggyback" after total dose of intermittent infusion is complete the primary line will resume
- "Concurrent" allows for simultaneous infusion of both primary and secondary lines to further dilute medication
- If the infusion can be diluted in 50 mL or less it is appropriate to utilize a syringe pump if a primary infusion is not in place
- If the medication requires dilution in greater than 50mL delivery should be through a secondary infusion in a minibag
- If the mini bag is necessary for one medication, then this patient should have all IV
  medications given via mini bag to preserve the secondary tubing unless the
  medication comes supplied in a syringe from pharmacy

#### 3. Volume controlled infusion:

- a small container, holding 50 to 150 mL of fluid, is attached below the primary infusion bag (Buretrol)
- IV medications administered above the drip chamber should be infused by the secondary port by mini bag and secondary tubing or syringe

#### 4. Below the Drip Chamber (BDC):

- injection of a bolus or small volume of medication through an existing IV infusion line or saline IV lock
- when a medication is ordered below the drip chamber (includes administration referred to as IV push, IV direct, IV side arm or retrograde IV techniques), it may be administered via the lower Y site of an infusing intravenous or via syringe through an established IV lock
- IV patency must be established prior to the administration of the medication
- The medication should be diluted (where applicable) to at least 2mL volume and is recommended to be given over 3 to 5 minutes depending on the dose. Dilution up to 10mL may be easier to calculate and give over several minutes. Note that not all drugs can be diluted e.g. Diazemuls
- When administered via the lower Y site the IV infusion should be turned off while administering the medication

#### **Preparing Medications**

Many IV drug solutions are prepared in the pharmacy department by pharmacists or pharmacy technicians. Occasionally, the nurse will need to prepare the IV drug solution.

When preparing a medication for IV administration, be sure to take some basic safety measures: maintain aseptic technique, always use good hand washing technique, and avoid contaminating any part of the ampule, vial, syringe, needle, or container that must remain sterile. When inserting the needle tip into the vial, and withdrawing it, be sure the needle tip does not touch any part of the vial that is not sterile. Use caution to avoid needle stick injuries.

Make sure you use a syringe that is large enough to hold the entire dose, when drawing up the drug before adding to the primary solution. The needle should be at least 2.5 cm (1 inch) long to penetrate the inner seal of the port on an IV bag. Occasionally a filter may be necessary (see miscellaneous instructions in the Ottawa Manual).

Frequently, pre-mixed doses are drawn up into a syringe in the pharmacy department. The nurse then administers the dose using a syringe pump or as a secondary on the infusion pump that delivers the medication over a predetermined time period.

All medications must have a completed medication label applied including medications that are prepared by pharmacy.

#### **Reconstitution of Drugs**

Many IV drugs are supplied in a vial in powder form and require reconstitution with such diluents as normal saline, or sterile water for injection. The manufacturer's instructions and the Ottawa Intravenous Therapy Manual will provide instructions about the appropriate type and amount of diluent. The pharmacy department is also available as a resource. Liquid drugs don't require reconstitution, but they may require further dilution.

- a) Draw up the type and amount of diluent specified by the manufacturer
- b) Clean the rubber stopper of the drug vial with an alcohol wipe using aseptic technique
- c) Insert the needle connected to the syringe of the diluent into the stopper at a 45 to 60-degree angle to minimize coring or breaking off of rubber pieces
- d) Mix thoroughly by gently inverting the vial or rolling between hands as indicated in manufacturer's information sheet. Do not shake vigorously because some drugs may froth
- e) If using a multi-dose vial affix a label indicating the date and time that you reconstituted the drug

<u>Note</u>: Do not use a vial that was reconstituted by someone else and has not been labeled. Always check the length of time that a drug is stable in solution and compare with the date and time of reconstitution on the label, if prepared and sent by pharmacy.

Some drugs come in double-chambered vials that contain powder in the lower chamber and diluent in the upper one. To combine these contents, apply pressure to the rubber stopper on top of the vial to dislodge the rubber plug separating compartments. The diluent will then mix with the drug in the bottom chamber.

#### **Patient Assessment**

Verify patient allergies and ask the patient about past experience with receiving medication in the solution bag. Explain the purpose of the medication and any effects he or she might experience. If the medication is likely to cause discomfort to the vein, ask the patient to alert you to this so you can regulate the flow or further dilute the medication if at all possible.

#### **Compatibility**

Most IV drugs are compatible with commonly used IV solutions, however the more complex the solution or drug the greater the risk of incompatibility. There are three types of incompatibility:

Physical incompatibility – also called pharmaceutical incompatibility; occurs most often with multiple additives. Signs include precipitate haze, gas bubbles and cloudiness.

Chemical incompatibility - results from drug breakdown or degradation when two or more substances react, cause changes that can produce undesirable effects. Factors affecting compatibility include drug concentration, pH of the solution, and volume of solution used to mix medications.

Therapeutic incompatibility – can be the result of order of mixing, temperature, light, and contact in solution time. An example of this is giving tetracycline too close to penicillin in which case the bacteriocidal effect of the penicillin is inhibited.

Check compatibilities in drug information resources such as the Ottawa Parenteral IV manual, manufacturers product insert, and compatibility charts. It is always advisable to flush IV lines between IV drug administrations.

<u>pH</u> is the term used to refer to the degree of hydrogen ions or the acidity of the solution. pH plays an important role in drug stability, solubility and compatibility. Generally, drugs and solutions that are to be mixed should have similar pH values to ensure compatibility and stability. A pH range of 3-5 is acceptable; however certain drugs such as Vancomycin, even when reconstituted and mixed correctly, have a high pH. Vancomycin is similar to vinegar or acetic acid, therefore as with all drugs, proper mixing and rate of administration is important. Reactions between acidic and alkaline drugs and solutions can occur.

If the drug mixture contains particulates or is discoloured, throw it away and start again. Do not administer to the patient.

# **Intermittent Infusions Using the IV Pump**

Steps	Rationale
Gather equipment and perform hand hygiene.	Prevent the spread of microorganisms.
Prime standard primary clave tubing with	
compatible IV solution.	
Determine method of secondary delivery of	If the medication can be delivered in 50 mL
medication (syringe/minibag).	or less draw the medication up in a labeled
	60 mL or smaller syringe or as prepared by
	pharmacy and luer onto the secondary clave
	port.
	If the patient has medications that require dilution in greater than 50 mL, a minibag
	and secondary tubing are to be used.
The secondary port must be cleansed with an	and secondary tubing are to be used.
alcohol wipe – 30 second friction rub.	
For pumps so equipped, deliver the overfill when	A small amount of air left in the syringe will
using the secondary tubing. Do not deliver the	prevent a proximal line occlusion alarm at
overfill when using a syringe.	the end of the syringe dose.
Cleanse the clave extension port on the patient's	g and a second
IV lock with an alcohol wipe -30 second friction	
rub.	
Establish patency with saline flush.	
Luer primary tubing onto the clave port and start infusion.	
On completion of infusion cleanse the lower Y site	
on the primary tubing with alcohol wipe $-30$	
second friction rub.	
Disconnect primary tubing from the extension set	Maintains the tubing in a closed system
and luer the tip onto the cleansed lower Y port.	format so you may re-use tubing if
	appropriate. End of tubing must be kept
	sterile and capped or connected to itself to
	close the tubing system, otherwise, discard.
Flush saline lock with 5 mL of normal saline.	
Document the medication on CMAR.	
Perform hand hygiene.	Prevents transmission. Routine practice.

### **Intermittent Infusions Using the Syringe Pump**

Steps	Rationale
Perform hand hygiene.	Prevent the spread of microorganisms.
Use preloaded syringe as supplied by pharmacy or prepare syringe per pharmacy guidelines.	Use of preloaded syringe decreases potential for error. Mixing as pharmacy guidelines ensures correct mix.
Luer medication syringe onto micro bore tubing and prime tubing.	After the first dose the tubing will remain primed and will not require priming again.
Insert medication syringe into syringe pump.	
Establish patency of IV access.	Flush saline lock per IV guidelines.
Luer micro tubing onto saline lock.	
Start syringe pump at appropriate speed setting.	Infusing a concentrated medication too quickly will irritate the vein.
When infusion is complete, clamp tubing, disconnect from saline lock and cover slip connector tubing tip with a sterile cap.	To maintain sterility of the system.
Flush the saline lock with 5 mL normal saline.	To maintain patency.
Leave medication syringe in place until next dose is required.	To maintain sterility. To maintain prime in the tubing.
When the next dose is due, remove used syringe and luer on fresh syringe. It is not necessary to purge the tubing of previous medication.	The tubing is micro bore 0.4 mL lumen volume making the interface between medications insignificant. Every medication will require reference to guidelines for infusion rate and concentration.
Document the medication on the CMAR.	
Perform hand hygiene.	Prevent the transmission of microorganisms.

<sup>\*\*</sup>Note: The syringe pump should not be used for delivery of any medication that requires precise delivery.

Administration sets for intermittent use (not part of a closed system) are to be changed every 24 hours.

### **Intravenous Bolus Medication**

Steps	Rationale
Verify the physician's order.	
Perform hand hygiene.	Prevent the spread of microorganisms.
<ul> <li>Equipment:</li> <li>Alcohol wipes</li> <li>Appropriate size syringe for medication dosage and dilution</li> <li>Two normal saline flushes</li> <li>Medication and diluent</li> </ul>	
Prepare medication by diluting with appropriate solution and volume as per the Ottawa Infusion Manual.	A minimum volume of 2 mL is recommended. Medications and allowable doses vary per patient unit.
Follow the eight rights of medication administration.	The right client, medication, reason, dose, frequency route, site, and time.
Explain procedure to the patient and obtain verbal/implied consent.	An informed patient can assist in detection of adverse reactions.
Establish patency of the saline lock by performing a saline flush and check the site and flow rate if using a continuous infusion.	To avoid inadvertent infusion of medication into the tissue.
Be aware of drug action, allergies, interactions and antidotes.	Bolus medications are absorbed totally and immediately. There is <b>NO ROOM FOR ERROR.</b>
Luer lock medication syringe onto the saline lock or the lowest Y site of a continuous infusion.	Turn off IV and pinch off tubing prior to bolus infusion.
Infuse <b>slowly.</b> Follow Ottawa Drug Manual guidelines.	Recommend infusion over 2 – 3 minutes or longer depending on patient's condition.
Close observation of the patient during bolus administration is essential. Stop infusion immediately and notify physician if any adverse reaction is noted.	Drug reactions may be sudden and intense.
Remove the medication syringe from port and flush per protocol.  **NOTE: To administer a HEPARIN BOLUS stop	Flushing ensures all medication is removed from the tubing.
the continuous infusion, disconnect the tubing and luer Heparin-filled syringe onto extension set port. Administer the bolus then restart the continuous infusion. Do not flush after the Heparin bolus.	To maintain consistent concentration of Heparin infusion with minimal interruption.
Reassess patient after intervention – normally 15 min to 30 min following IV bolus and then again as required. Document medication administration and your reassessment.	To meet standards of practice and provide safe patient care.

# **Complications of Intravenous Therapy**

COMPLICATIONS	DEFINITION	SIGNS AND SYMPTOMS	CAUSE	INTERVENTION
Phlebitis	Inflammation of the vein	<ul><li>Pain</li><li>Tenderness</li><li>Erythema</li></ul>	<ul> <li>PH, osmolality of solution, medication</li> <li>Injury to the vein</li> <li>Inadequate stabilization</li> <li>PVAD gauge too large for vessel</li> </ul>	<ul> <li>Remove PVAD</li> <li>Elevate extremity</li> <li>Warm, moist compress</li> <li>Appropriate comfort measures</li> </ul>
Extravasation	Infiltration of vesicant or irritant drug into the surrounding tissue. Can cause tissue necrosis or blistering.	<ul> <li>Erythema</li> <li>Edema</li> <li>Pain</li> <li>Burning</li> <li>Loss or change in blood return</li> </ul>	Medication being administered into the surrounding tissue inadvertently	Stop medication infusion and notify Dr.     Do Not remove PVAD until antidote has been given     Aspirate any residual vesicant from the cannula and administration set     Administer appropriate antidote     Apply heat or cold     Do not apply pressure to the site     Document findings     Photograph site for later comparison
Infiltration	Fluid administration into surrounding tissues.	<ul> <li>Pain</li> <li>Edema</li> <li>Cool skin</li> <li>↓ flow rate</li> </ul>	Puncturing of vein wall during insertion or during infusion	<ul> <li>Remove PVAD and resite</li> <li>Elevate extremity</li> <li>Appropriate comfort measures</li> <li>Monitor site for adverse effects</li> </ul>
Fluid Overload	Excess fluid volume.	<ul> <li>↑BP</li> <li>Dilation of neck veins.</li> <li>SOB</li> <li>Tachypnea with rales.</li> </ul>	Infusion rate > what the pt. can tolerate	<ul> <li>Slow infusion to TKVO rate</li> <li>Place pt. in High Fowler's</li> <li>Notify Dr.</li> <li>Monitor V/S, intake &amp; output</li> </ul>
Speed Shock	Systemic reaction	• Syncope	Too rapid rate of	Discontinue medication

### Intravenous Guidelines for the Adult Patient

	that occurs when a foreign substance is rapidly introduced into the circulatory system.	<ul> <li>Headache</li> <li>Flushed face</li> <li>Tightness in the chest</li> <li>Irregular pulse</li> <li>Hypotension</li> <li>Shock and cardiac arrest may occur</li> </ul>	infusion or bolus	<ul> <li>infusion</li> <li>Maintain IV at TKVO</li> <li>Notify Dr.</li> <li>Monitor pt.</li> </ul>
Catheter Embolism	A portion of the catheter is carried into the circulatory system and has the potential to impede and/ or obstruct circulation	<ul> <li>May be asymptomatic</li> <li>Hypotension</li> <li>Tachycardia</li> <li>Diaphoresis</li> <li>Cyanosis</li> <li>Loss of consciousness</li> </ul>	Can occur when the stylet is reintroduced into the device     May occur upon insertion when the device is withdrawn through the needle introducer	Discontinue IV and inspect device for rough edges     If catheter has fragmented, apply tourniquet above the site and obtain an X-ray     Notify physician     Bedrest
Thrombosis	Blood clot within a blood vessel.	<ul> <li>Erythema at site</li> <li>Tenderness</li> <li>Edema</li> <li>Pain</li> </ul>	Trauma to vessel due to PVAD too large for vein PVAD in situ > 96 hrs. Venous stasis Meds or solutions with high pH or tonicity Incompatibility with medication and solution Multiple venipunctures	<ul> <li>Remove IV</li> <li>Apply cold compresses to ↓blood flow</li> <li>Notify Dr.</li> <li>Monitor site</li> </ul>
Site Infection	Infection where cannula enters the skin.	<ul> <li>Erythema</li> <li>Edema</li> <li>Pain</li> <li>Purulent discharge</li> <li>Fever</li> </ul>	Break in aseptic technique     Use of contaminated equipment     Improper handwashing prior to initiation	<ul> <li>Remove PVAD</li> <li>Culture site and PVAD tip</li> <li>Notify Dr.</li> <li>Review technique for inserting PVAD</li> </ul>

# **Trouble Shooting**

Problem	Resolution
High skin resistance – extremely tough skin due to tanning, weather beaten.	Increase the angle of the catheter so that the tip of the stylet breaks the skin. Maintain skin tautness.
Fragile skin and veins.	Use BP cuff instead of the tourniquet. Use low angle approach with gentle vein stabilization.
No flashback in the chamber.	Ensure complete entry into the vein. Change angle and advance the PVAD. Stabilize the vein (rolling veins use counter traction). Redirect the PVAD. <b>DO NOT PROBE.</b>
Resistance when threading the PVAD into the vein.	Remove the tourniquet. If there is visible flashback, connect the IV and run solution slowly. Advance the PVAD with the infusion of solution. If unable to advance, remove PVAD and apply pressure to site.
Infiltration.	Remove PVAD, apply pressure.
	Reinitiate IV proximal to the site of infiltration or in the opposite limb.
Maintaining the flow rate.	Gravity infusions should hang 1 metre above the site. If the insertion site is below a joint (e.g. the wrist) try using an arm board to stabilize.

#### References

BD PVAD initiation video link:

http://www.bd.com/infusion/products/ivcatheters/resources/

- Canadian Intravenous Nurses Association. (1999). *Intravenous therapy guidelines*, (2<sup>nd</sup> ed.). Toronto: Canadian Intravenous Nurses Association.
- College of Nurses of Ontario. (2015). *Medication practice standard*. College of Nurses of Ontario. Toronto: Author.
- Infusion Nurses Society. (2016). *Infusion nursing standards of practice*. Journal of Infusion Nursing *34*(1S). S11-S125.
- Perry, AG. & Potter, P.A. (2010). Clinical nursing skills and techniques, (7<sup>th</sup> ed.). St.Louis: Mosby.
- Registered Nurses Association of Ontario. (2008). *Care and maintenance to reduce vascular access complications*. RNAO. Toronto: Author.

The Ottawa Hospital. (2018). Parenteral Drug Therapy Manual. (39th ed.)

# Appendix A



# QUINTE HEALTHCARE CORPORATION

# Appendix A

# Intravenous Certification

Name:Unit:	_	
Completed	Date	Signature
<ol> <li>Attendance at IV Therapy Theory taught in a classroom environment.</li> </ol>		
2. Demonstration Lab.		
3. Two successful supervised IV initiations.		
has met the crit Healthcare and is approved for Independent Practice of Intravence		
Date:		
Signature: Employee Signature	e.	

# Appendix A



### QUINTE HEALTHCARE CORPORATION

### Intravenous Certification - Skills Checklist

		#1	#2
1.	Confirms Prescriber Orders.		
2.	Explains procedure to patient/family.		
3.	Checks solution for colour, clarity and expiration date.		
4.	Maintains aseptic technique when preparing infusion set.		
5.	Identifies suitable site for IV initiation.		
6.	Performs visual inspection of the IV device and rotates the hub to ensure it moves freely.		
7.	Applies tourniquet 10 -12 cm above the site.		
8.	Checks for distal pulse.		
9.	Prepares insertion site with alcohol swab, using a circular motion from site to periphery.		
10.	Appropriately performs vein stabilization (as required).		
11.	Advances the catheter off the stylet without contaminating the IV.		
12.	Presses the white button to retract the stylet safely.		
13.	Connects the device (clave or extension set) and ensures that the luer lock connection is tight.		
14.	Checks for free flow of fluid.		
15.	Secures IV device with appropriate dressing and applies the date/time label.		
16.	Documents appropriately on the patient health record.		
Sig	mature and Comments of Supervising Health Care Professional #1:		
Su	pervising Health Care Professional #2:		

#### Appendix B

#### Certification Test for Initiation of PVAD and Infusion Therapy

- 1. Reasons for establishing a peripheral vascular access device (PVAD) include:
  - a. To maintain or replace body stores of water, electrolytes and vitamins
  - b. To replenish blood loss or administer blood component
  - c. To provide a route for administration of medications
  - d. All of the above
- 2. What isotonic fluid is infused with a blood transfusion?
  - a. Dextrose 5% in water
  - b. Lactated Ringers
  - c. Sodium Chloride 0.9%
  - d. All of the above
- 3. A hypertonic solution would be:
  - a. Sodium chloride 0.45%
  - b. Dextrose 5% in water
  - c. Dextrose 10% in water
  - d. 3.3% Dextrose in 0.3% sodium chloride (2/3 & 1/3)
- 4. The tourniquet can be left on a maximum of 2 minutes.
  - a. True
  - b. False
- 5. Factors affecting the site selection include:
  - a. Size of PVAD required for a specific therapy
  - b. Patients activity level
  - c. Duration of the infusion therapy
  - d. Condition of the patient's veins
  - e. All of the above
- 6. Initiation of a PVAD in areas of flexion increases the risk for phlebitis, infiltration and excessive vessel damage.
  - a. True
  - b. False
- 7. It is acceptable to use an area within 5 cm of the wrist to initiate a PVAD.
  - a. True
  - b. False
- 8. Signs of fluid overload in a patient receiving a continuous IV infusion at a rate of 100cc/hr would include:
  - a. Crackles in the lungs
  - b. Coughing up sputum
  - c. Shortness of breath
  - d. Tachypnea
  - e. A, C and D
  - f. A and C

9	APVA	AD should not be left in place longer than hours.
10.	Tubing	g changes for continuous (non-interrupted IV infusions) is every hours.
11.	_	of phlebitis in a vein would include: Swelling
		Cool skin
		Decreased flow rate
		Pain
		Erythema
		A, B, and D D and E
		All of the above
	11.	
12.	Name	three signs of infiltration:
	c.	
		VAD insertion site should be assessed for inflammation, infiltration, tenderness, oration and patency every:
		Hour
	b.	Q2h
		Q shift
	d.	When each new bag is hung
14.	Docun	nentation for a PVAD insertion includes which information:
	a.	Patient tolerance of procedure, color of angiocath used, site selected, time and date
		Size of angiocath used, site selected, number of attempts, patient tolerance of
		procedure and any complications, time and date
	c.	Site selection, number of attempts, patient allergies, time and date